

Almond Butter Chocolate Chip Cookies

(Flourless)

Submitted by Shannon Lazar, as found at www.cleaneatingmag.com



1 cup unsalted almond butter, stirred well
¾ cup sucanat (or sugar)
1 large egg
½ tsp baking soda
¼ tsp sea salt
3 oz dark chocolate, broken into small pieces

Preheat oven to 350°. In a medium bowl stir together first 5 ingredients until blended. Stir in chocolate.

Drop dough by rounded tablespoonfuls onto parchment-lined baking sheets. Bake for 10-12 minutes or until lightly browned. Let cool on baking sheets for 5 minutes. Remove to a wire rack and let cool for 15 more minutes.

